



DESKTOP - FOLDING DISPLAY BOARDS
 user instructions

1



Remove the folding desktop display boards from their packaging and place upright, on a desk or display surface, as shown.

2



Hold the two end boards and pull outward to unfold the display boards.

3



Your desktop display boards unfolded and ready for use.

4



If you have ordered the optional header display board, place two locking clips in the top centre board aluminium edging.

5



Ensure the arrow and word 'lock' on the locking clips face outwards as shown.

6



Place the header panel on the centre display board, as shown.

7




Slide the locking clips fully over to each edge. Ensure they lock into place.

8



Your desktop folding display boards and header are now ready for use.

9



The desktop display boards come supplied with foot pegs. Insert these as shown, for additional support and maneuverability.