

FLEXI- SCREEN INSTRUCTIONS

user instructions

1



Remove the folding panels from the packaging and stand upright on a flat surface.

2



Hold the end panel and pull outward to unfold the panels.

3



If you are linking two Flexi- Screens together use the linking strip provided by slotting into the edging channel.

4



Your Flexi- Screen is now ready to use.