

MOBI FOLDING DISPLAY SCREENS

user instructions

1



Remove the folding panels from the packaging and stand upright on a flat surface.

2



Hold the end panel and pull outward to unfold the panels.

3



When in position fit the stabilising feet to the panels by slotting into place and tightening until the foot is securely in place.

4



5



All mobi 6 panels and above have an additional centre stabilising foot for extra stability.

